
# Pressure gauge

## G1-40-F11·G3-40-F11

## **Symbol**



#### **Order codes**



## **Specifications**

Item		Model	G1-40-F11	G3-40-F11
Medium			Air	
Port size			NPT1/4 (M5×0.8)	
Pressure indicator range		psi	0 to 145	0 to 43.5
Accuracy			F.S.±3%	
Outside diameter		in	1.575	
Maximum operating pressure		psi	134.9	36.3
Operating temperature range (atmosphere and media)		°F	41 to 140 (non-condensation)	
Mass		OZ	3.17	
Materials	Case		ABS	
	Connection port thread		Brass	
	Bourdon tube		Brass	

## Pressure gauge dimensions in.


## ●G1-40-F11

Pressure gauge





●G3-40-F11



## Handling instructions and precautions





The pressure gauge is a precision measuring device. Be careful of impacts and vibrations.

## Mounting and piping

During mounting and piping operations, do not grab the pressure gauge body to tighten. For tightening, always use a wrench on the piping connection port's square portion. Use a tightening torque of 2.21 to 3.69 ft•lbf if the pressure gauges are mounted on the pressure port plate with NPT1/4.

## Preset marker

You can set the preset marker. Rotate the cover ring to first set the low pressure and then set the high pressure.



