


MICRO EJECTORS

ME03, ME05, ME07



Specifications

Basic model		ME03 □ME03-E1	ME05 □ME05-E1	AME05-E2	ME07 □ME07-E1	AME07-E2
Media		Air				
Operating pressure range MPa [psi.]		0.1~0.6 [15~87]	0.1~0.6 [15~87]	0.2~0.6 [29~87]	0.1~0.6 [15~87]	0.2~0.6 [29~87]
Proof pressure MPa [psi.]		1.03 [149]				
Operating temperature range °C [°F] (atmosphere and media)		Without solenoid valve				
		0~50 [32~122] (No freezing)				
		With solenoid valve				
		5~50 [41~122]				
Nozzle diameter mm [in.]		0.3 [0.012]		0.5 [0.020]		0.7 [0.028]
Vacuum ^{Note 1} kPa [in.Hg]		-80 [-23.6]		-86.7 [-25.6]		
Vacuum flow rate ^{Note 1} ℓ /min [ft. ³ /min.] (ANR)		3.0 [0.106]		6.3 [0.222]		12.5 [0.441]
Compressed air consumption ^{Note 1} ℓ /min [ft. ³ /min.] (ANR)		4.5 [0.159]		11.5 [0.406]		23.0 [0.812]
Lubrication		Prohibited				
Filtration μm		30 (manifold only)				
Port size ^{Note 2}		Vacuum generation port		Compressed air supply port		
		M5×0.8	M5×0.8	Rc1/8	M5×0.8	Rc1/8
Mounting direction		Any				
Main valve specifications		Operation type				
		Direct operating				
		Number of positions, number of ports				
		2 positions, 2 ports				
		Valve function				
		Normally closed (NC standard) or normally open (NO optional)				
Effective area mm ² [Cv]		0.2 [0.01]		0.6 [0.03]		0.8 [0.04]
Shock resistance		Piping direction m/s ² [G]		Axial direction m/s ² [G]		
		1372.9 [140]	1372.9 [140]	117.7 [12]	1372.9 [140]	147.1 [15]
Manual override		Non-locking type (Standard)		Non-locking type (standard) or locking protruding type (Optional)		

Notes: 1. Value (approximate) at pressure of 0.5MPa [73psi.]. For details, see p.702.
2. For details, see the port size table.

Solenoid Specifications

Rated voltage		DC12V	DC24V	AC100V	AC200V
Item		Micro ejector basic model			
		□ME03-E1 ^{Note}	□ME05-E□	□ME07-E□	
Type		With built-in flywheel diode for surge suppression		Shading type	
Operating voltage range V		10.8~13.2 (12±10%)	21.6~26.4 (24±10%)	90~132 (100±32%)	180~264 (200±32%)
Current (When rated voltage is applied)	Frequency Hz	—		50	60
	Starting mA(r.m.s.)	—		36	32
	Energizing mA(r.m.s.) (with LED indicator)	130 (140)	70 (80)	65 (75)	24
Maximum allowable leakage current mA		15	5	4	2
Insulation resistance MΩ		100 or more			
Wiring and lead wire length		Standard			
		Grommet type : 300mm			
		Optional			
		Plug connector type: 300mm, (1L : 1000mm) Made to order (3L : 3000mm)			
Color of lead wire		Brown (+) Black (-)	Red (+) Black (-)	Yellow	White
Color of LED indicator (Optional)		Red		Yellow	Green
Surge suppression (as standard)		Flywheel diode		Varistor	

Note: ME003-E1 can be manufactured at DC5V and DC6V. For delivery times, consult us.

Electronic Vacuum Switch Specifications

Item	Model	PS310E	
Media		Air or non-corrosive gas	
Operating temperature range °C [°F]		-10~60 [14~140] (No freezing)	
Operating humidity range %RH		35~95	
Operating pressure range kPa [in.Hg]		-101.3~0 [-29.92~0]	
Proof pressure MPa [psi.]		0.2 [29]	
Pressure setting range kPa [psi.]		-101.3~10.1 [-14.7~1.5]	
Hysteresis ^{Note} %		2~9	
Repeatability		Within ±3%FS (0~50°C) [32~122°F]	
Electrical specifications		Operating type	
		NPN open collector output , NO type (Output ON when falls below set pressure)	
		Operating voltage range DCV	
		12~24±10% (ripple Vp-p10%) or less	
		Switching capacity	
		DC30V, 100mA or less (Internal voltage drop: 1V or less at load current 100mA, 0.4V or less at load current 16mA)	
Consumption current mA MAX.		20	
Insulation resistance MΩ		100 or more (DC500V megger, between charging part and case)	
Surge suppression		Zener diode (As standard)	
Mechanical characteristics		Shock resistance m/s ² [G]	
		490.3 [50]	
Vibration resistance		10~55Hz (total amplitude 1.5mm [0.06in.]) or 98.1m/s ² [10G] (2 hours at each X-, Y-, Z-axis MAX.)	
Operations indicator		When ON, LED indicator lights up	
Lead wire		Vinyl cabytre: 0.14SQ×3-lead×500mm (Overall length)	
Mounting direction		Any	
Materials (Body cover)		Plastic	


Note: Values are at a set pressure of -86.7kPa [-25.6in.Hg].

Port Size


Basic model		Port size	
		Vacuum generation port	Compressed air supply port
Micro ejector	ME03, ME03-E1	M5×0.8	M3×0.5
	ME05, ME05-E1		M5×0.8
	ME07, ME07-E1	Rc1/8	M5×0.8
Manifold	ME03M□A	M5×0.8	Rc1/8
	ME05M□A, ME05M□AS	M5×0.8	Rc1/8
	ME07M□A, ME07M□AS		Rc1/8

Micro Ejector Order Codes

● Micro ejector single unit (without solenoid valve)




● Micro ejector with solenoid valve



Notes: 1. Only for solenoid valve for controlling supply air. The solenoid valve for controlling vacuum breaking air is normally closed (NC) only.

2. Lead wires in the **1L**: 1000mm [39in.] and **3L**: 3000mm [118in.] lengths are available as made to order for the plug connector type.


Manifold Order Codes



Notes: 1. For mountings of micro ejector options, see the micro ejector order codes. Also, if not mounting a micro ejector, and placing a block-off plate on the station instead, enter **-BP**.


2. Lead wires in the 2000mm [79in.] length are available as made to order for the electronic vacuum switch.

Electronic Vacuum Switch Order Codes




Additional Parts (to be ordered separately)

● Block-off plate




● Replacement filter




Operation Principle and Major Parts


● De-energized



● When energizing a solenoid valve for controlling supply air (generating vacuum)



● When energizing solenoid valve for controlling vacuum breaking air




Major Parts and Materials

Parts		Materials
Micro ejector	Body	Aluminum alloy (anodized)
	Adapter	Aluminum alloy (anodized)
	Nozzle, diffuser	Brass
	O-ring	Synthetic rubber (NBR)
	Gasket	Synthetic rubber (NBR)
	Plunger	Magnetic stainless steel
Manifold	Column	Magnetic stainless steel
	Body	Aluminum alloy (anodized)
	Seal	Synthetic rubber (NBR)
	Filter	Plastic (PVF)
	Block-off plate	Mild steel (nickel plated)

Symbols


Single unit

●ME03 ●ME05 ●ME07




With single solenoid valve

●ME03-E1 ●ME05-E1 ●ME07-E1




With single solenoid valve

●AME03-E1 ●AME05-E1 ●AME07-E1
(Manifold mounted)




With single solenoid valve and vacuum switch

●AME05-E1-□-E ●AME07-E1-□-E
(AS type manifold mounted)




With twin solenoid valves

●AME05-E2 ●AME07-E2
(Manifold mounted)



With twin solenoid valves and vacuum switch

●AME05-E2-□-E ●AME07-E2-□-E
(AS type manifold mounted)



Mass

●Micro ejectors

g [oz.]

Item	Basic model	ME03	ME05	ME07
Without solenoid valve		9 [0.32]	34 [1.20]	52 [1.83]
With single solenoid valve ME□-E1		24 [0.85]	80 [2.82]	103 [3.63]

●With electronic vacuum switch

PS310E (For mounting AS type manifold).....21g [0.74oz.]
PS310E-01 (For mounting single unit).....38g [1.34oz.]

●Manifolds

g [oz.]


Item	Model	ME03		ME05		ME07	
		ME03M□A	ME05M□A	ME05M□AS	ME07M□A	ME07M□AS	
Manifold body for number of units	1 unit	26 [0.92]	62 [2.19]	81 [2.86]	120 [4.23]	148 [5.22]	
	2 units	49 [1.73]	118 [4.16]	154 [5.43]	237 [8.36]	292 [10.30]	
	3 units	64 [2.26]	156 [5.50]	202 [7.13]	313 [11.04]	385 [13.58]	
	4 units	80 [2.82]	193 [6.81]	251 [8.85]	389 [13.72]	478 [16.86]	
	5 units	95 [3.35]	231 [8.15]	299 [10.55]	465 [16.40]	571 [20.14]	
Additional mass	With single solenoid valve -AME□-E1	25 [0.88]	83 [2.93]		108 [3.81]		
	With twin solenoid valve -AME□-E2	—	167 [5.89]		216 [7.62]		
	With electronic vacuum switch -E	—	—	21 [0.74]	—	21 [0.74]	
	Block-off plate -BP	2 [0.07]	6 [0.21]		13 [0.46]		

Calculation example : ME05M5AS

stn.1~2-AME05-E1


stn.3~4-AME05-E2-E

stn.5 mass of -BP 299 + (83 × 2) + (167 + 21) × 2 + 6 = 847g [29.88oz.]




Dimensions of ME05 (mm)

ME05 Single unit




ME05-E1 With solenoid valve



ME05M□A A type manifold

● In the case of 1 unit




Unit dimensions

Model	L	P
ME05M2A	50	40
3A	66	56
4A	82	72
5A	98	88

Dimensions of ME05 (mm)

ME05M□AS

AS type manifold



Unit dimensions


Model	L	P
ME05M2AS	50	40
3AS	66	56
4AS	82	72
5AS	98	88

Options

● Solenoid with straight connector : -PSL

● Solenoid with L connector : -PLL


● Locking protruding type manual override : -83




Model	Code	A	B	C	D	l (Lead wire length)
ME05-E1, AME05-E1		84	59	76	70	-PSL, -PLL : 300
AME05-E2		131.5	72	115.5	83	Made to order : 1L ; 1000, 3L ; 3000

Dimensions of ME07 (mm)

ME07 Single unit




ME07-E1 With solenoid valve



ME07M□A A type manifold

● In the case of 1 unit




Unit dimensions

Model	L	P
ME07M2A	59	49
3A	78	68
4A	97	87
5A	116	106


Dimensions of Electronic Vacuum Switch (mm)

PS310E-01




Air Consumption, Vacuum and Vacuum Flow Rate


ME03



ME05



ME07




Remark: Graphs are for each single ejector unit. If the unit with solenoid valve requires the same vacuum level, set the supply pressure 0.03~0.05MPa [4.4~7.3psi.] higher than the single ejector unit's case.


1MPa = 145psi. 1kPa = 0.145psi. -100kPa = -29.54in.Hg 1 l/min = 0.0353ft³/min.

Time to Reach Vacuum and Vacuum Breaking Time

Measurement method



ME□-E1




Air pressure: 0.5MPa [73psi.]
Adjusting needle for vacuum breaking flow: Fully open
t₁: Time to reach -73.3kPa [-21.65in.Hg] in the chamber after energizing S1.

t₂: In ME□-E1, time to reach -18.7 kPa [-5.52in.Hg] in the chamber after de-energizing S1.

t₃: In ME□-E2, time to reach -18.7kPa [-5.52in.Hg] in the chamber after energizing S2 and when vacuum was at its maximum level.

ME□-E2




Response time

Model	Chamber capacity cm ³ [in. ³]	5 [0.305]			10 [0.610]			20 [1.22]			50 [3.05]			100 [6.10]			200 [12.2]			500 [30.5]		
		t ₁	t ₂	t ₃	t ₁	t ₂	t ₃	t ₁	t ₂	t ₃	t ₁	t ₂	t ₃	t ₁	t ₂	t ₃	t ₁	t ₂	t ₃	t ₁	t ₂	t ₃
ME03		0.4	0.1	—	0.7	0.2	—	1.1	0.3	—	3.2	0.6	—	5.8	1.1	—	—	—	—	—	—	—
ME05		0.2	0.1	0.1	0.3	0.1	0.1	0.5	0.1	0.1	1.5	0.3	0.1	2.6	0.5	0.2	7.0	0.8	0.4	12.0	1.8	0.8
ME07		0.1	0.1	0.1	0.2	0.1	0.1	0.3	0.1	0.1	0.6	0.2	0.1	1.0	0.3	0.2	1.8	0.4	0.4	4.7	1.0	0.8


Note: Some degree of variation may occur due to piping size and chamber shape. The figures can be viewed as a guide.

Handling Instructions and Precautions



Micro Ejector

Device configuration




※The illustration shows ME05M2AS stn.1-AME05-E2-□
stn.2-AME05-E1-□-E.


Functions

In addition to a single unit, the Micro Ejector ME03/05/07 series offer models with single solenoid valves for controlling supply air, and with twin solenoid valves for controlling supply air and vacuum breaking air (twin solenoid valves are for AME05/07 only). The unit with twin solenoid valves uses supply of pressurized air to the vacuum side to enable vacuum breaking and blow-off release, and makes use of an adjusting needle for vacuum breaking flow to enable flexible setting of breaking flow. In addition, a built-in check valve ensures that the setting of vacuum level can be maintained even when the power to the solenoid valve for controlling supply air has been switched off, attaining energy savings.

●Control circuit for economizing on air consumption volume when the vacuum is being maintained for long periods of time



Remark: The above diagram shows the case when the solenoid valve for controlling supply air is normally open (NO; order code: -11).



Piping

1. Connect air supply to the compressed air supply port, and a vacuum pad, etc., to the vacuum generation port.
2. In manifolds with two or more units, P ports (compressed air supply ports) are located on both ends of the manifold, and the piping direction can be selected according to the mounting location. At time of delivery, a port on one side is temporarily blocked off with a plug. Remove the plug and then use sealing tape or other sealing material to re-tighten.
3. Use a block-off plate (order code: ME□MA-BP) to block off unused stations on the manifold.
4. For piping to the micro ejector, use a nylon or urethane tube with inner diameter of $\phi 4 \sim \phi 6$ [$\phi 0.157 \sim \phi 0.236$ in.]. For vacuum generation ports, tubes of the following sizes are recommended.
ME03... $\phi 4 \times 2.5$
ME05... $\phi 4 \times 2.5, \phi 6 \times 4$
ME07... $\phi 6 \times 4$

- Cautions:**
1. Use a fitting that does not reduce inner diameter. A small inner diameter can result in degradation of performance, including pressure shortages, insufficient vacuum, or longer periods of time before the vacuum level is reached.
 2. Avoid use of coil tubes and other curved piping. Also, avoid use of elbow fittings, etc., between the micro ejector and vacuum pad, and use piping that is as straight as possible.
 3. In manifolds with many units, where a large number of micro ejectors are operating simultaneously, or where the operation frequency is very high, supply air from P ports on both ends.




Solenoid

Internal circuit


● DC12V, DC24 (surge suppression)

Standard solenoid




Solenoid with LED indicator

Order code: -PSL, -PLL




● AC100V, AC200V (surge suppression)

Standard solenoid



Solenoid with LED indicator

Order code: -PSL, -PLL



- Cautions:**
1. Do not apply megger between the lead wires.
 2. For DC12V, DC24V, while there is no danger with a solenoid of a short circuit by the wrong polarity, the valve will not operate.
 3. Leakage current inside the circuit could result in failure of the solenoid valve not to return to home position or other erratic operation. Always use within the range of the allowable leakage current. If circuit conditions, etc., cause the leakage current to exceed the maximum allowable leakage current, consult us.




Plug connector

Attaching and removing plug connector


Use fingers to insert the connector into the pin, push it in until the lever claw latches onto the protruded section on the connector housing, and complete the connection.

To remove the connector, squeeze the lever along with the connector, lift the lever claw up from the protruded section of the connector housing, and pull it out.



Crimping of connecting lead wire and contact

To crimp lead wires into contacts, strip off 4mm [0.16in.] of the insulation from the end of the lead wire, insert it into the contact, and crimp it. Be sure to avoid catching the insulation on the exposed wire crimping section.




- Lead wire □ ME03 Equivalent to AWG 28
 □ ME05
 □ ME07 Equivalent to AWG 24

Attaching and removing contact and connector

Insert the contact with a lead wire into a plug connector □ hole until the contact hook latches on the connector and is secured to the plug connector. Confirm that the lead wire cannot be easily pulled out.

To remove it, insert a tool with a fine tip (such as a small screwdriver) into the rectangular hole on the side of the plug connector to push up on the hook, and then pull out the lead wire.



- Cautions:**
1. Do not pull hard on the lead wire. It could result in defective contacts, breaking wires, etc.
 2. If the pin is bent, use a small screwdriver, etc., to gently straighten out the pin, and then complete the connection to the plug connector.
 3. For crimping of connecting the lead wire and contact, always use a dedicated crimping tool.
 Contact: Model 702062-2M
 Manufactured by Sumiko Tech, Inc.
 Crimping tool: Model F1-702062
 Manufactured by Sumiko Tech, Inc.




Manual override


Non-locking type and locking protruding type

To operate non-locking type, use a tool with a thin tip (such as a small screwdriver) to press the manual override all the way down. The micro ejector works the same as an energized state as long as the manual override is pushed down, and returns to the reset position upon release.

To lock the locking protruding type manual override, use fingertips or a small screwdriver to push down on the manual override all the way and turn it 45 degrees or more. Either turning direction at this time is acceptable. When locked, turning the manual override from the locking position releases a spring on the manual override, returns it to its original position, and release the lock. If manual override is not turned, this type acts just like the non-locking type. The micro ejector works the same as an energized state as long as the manual override is pushed down, and returns to the reset position upon release.




Caution: Always release the lock on the locking protruding type manual override before commencing normal operation.



Vacuum breaking

Adjustment of vacuum breaking flow rate

Rotate the adjusting needle for vacuum breaking flow (with twin solenoid valves only) in the clockwise direction to reduce the breaking flow rate, and in the counterclockwise direction to increase the breaking flow rate.




Handling Instructions and Precautions



Electronic Vacuum Switch


Pressure regulation

Rotate the pressure adjusting screw (SET) to set the pressure. Rotating the pressure adjusting screw to the right (clockwise) increases the vacuum setting. In addition, use the hysteresis adjusting screw (HYS) to set the hysteresis. Rotating the hysteresis adjusting screw to the right (clockwise) increases the hysteresis by shifting the OFF position.



- Cautions:**
1. To set the pressure and hysteresis, use the special screwdriver provided or a small screwdriver of appropriate size, and adjust by rotating them carefully without applying excessive force.
 2. To ensure accurate pressure setting, use a pressure gauge to perform the setting while switching the vacuum switch on and off.
 3. Do not apply pressure to the pressure detection area of more than 0.2MPa [29psi.].

Wiring instructions




- Brown: Lead wire for connecting the (+) polarity that activates the switch
- Black: Lead wire for connecting the load
- Blue: Lead wire for connecting the (-) polarity

- Cautions:**
1. Do not subject the lead wires to strong pulling force or excessive bending.
 2. Pay attention to the lead wire colors to connect. While the lead wires between brown and blue, for connecting to the power supply, are protected by diodes for protection of reverse current, the output circuits do not have a surge current protection function. Miswiring could cause damage to the output transistor.
 3. Do not connect and use the vacuum switch with a load that exceeds its switching capacity.

Mounting

1. As subjecting the vacuum switch to strong shocks could lead to damage or erratic operation, be careful when handling it.
2. Do not apply a wrench to the body cover when mounting as a single unit (PS310E-01). When tightening, always apply the wrench to the metal part of the adapter.



General precautions

1. If using in locations subject to dripping water, dripping oil, etc., or to large amounts of dust, use a cover to protect the unit.
2. Always thoroughly blow off (use compressed air) the piping before connecting it to the micro ejector. Intrusion into the piping of chips, sealing tape, rust, or other foreign material generated during piping operations could result in valve air leaks or a degradation in micro ejector performance.
3. Use clean air that does not contain deteriorated compressor oil or other contaminants. Install an air filter (with filtration of a minimum 40 μm) close to the micro ejector to eliminate any collected liquids or dust in air line. Always use a mist filter for cases where the pressurized air contains large amounts of oils. Moreover, drain the air filter at regular intervals.
4. Use a regulator to adjust the pressure of air supplied to the micro ejector. Where the piping length to the micro ejector is long, set the pressure at a little higher than normal. If using an air supply valve, use a valve with an effective area that is at least three times as large as the area of the micro ejector nozzle.
5. Use one vacuum pad for one micro ejector. Use of two or more pads could result in picking errors, and extend the amount of time required to reach the set vacuum level.
6. At periodic intervals, replace the filters (order code: ME□ MA-F) installed as standard equipment with the micro ejector body.

MICRO EJECTORS

ME12, ME25, ME60



Specifications

● Micro ejectors

Item	Model	ME12	ME25	ME60
Media		Air		
Operating pressure range	MPa [psi.]	0.1~0.6 [15~87]		
Operating temperature range	°C [°F]	0 ~ 50 [32~122] (No freezing)		
Nozzle diameter	mm [in.]	0.7 [0.028]	1.0 [0.039]	1.5 [0.059]
Vacuum ^{Note}	kPa [in.Hg]	-92 [-27.2]		
Vacuum flow rate ^{Note}	ℓ/min [ft. ³ /min.] (ANR)	12.5 [0.441]	25 [0.88]	58 [2.05]
Compressed air consumption ^{Note}	ℓ/min [ft. ³ /min.] (ANR)	23 [0.81]	46 [1.62]	107 [3.78]
Lubrication		Prohibited		
Filtration	μm	30		
Port size		Rc1/8	Rc1/4	

Note: Value is measured at air pressure of 0.5MPa [73psi.].

● Vacuum switches

Item	Operation	When NO	When NC
Setting vacuum	kPa [in.Hg]	-26.7~-80 [-7.89~-23.6]	
Response differential	kPa [in.Hg]	-5.3~-13.3 [-1.57~-3.94]	
Color of connected lead wire		Black, white	Black, red
Electric rating		5A/AC250V, 5A/DC24V (resistance load)	

Remark: For the internal switch, JIS-S2H1PO1 or equivalent is used.

● Single and twin solenoid valves

Item	Basic model	For ME12		For ME25, ME60				
		Single solenoid valve		Single solenoid valve		Twin solenoid valves ^{Note}		
		ME12E1		125EE1		125EE2		
Operation type		Direct operating		Direct operating				
Number of ports		2 ports (NC, NO)		2 ports (NC)				
Port size		Rc1/8		Rc1/4				
Proof pressure	MPa [psi.]	1.03 [149]		1.03 [149]				
Effective area	mm ² [Cv]	1.5 [0.08]		3 [0.16]				
Maximum operating frequency	Hz	5		5				
Mounting direction		Any		Any				
Voltage type		AC100V (Lead wire: yellow) AC200V (Lead wire: white) DC24V (Lead wire: red, black)		AC100V (Lead wire: yellow, black) AC200V (Lead wire: white, black) DC24V (Lead wire: red, black)				
Operating voltage range	AC100V	90~110V (100V±10%)		90~110V (100V±10%)				
	AC200V	180~220V (200V±10%)		180~220V (200V±10%)				
	DC24V	21.6~26.4V (24V±10%)		21.6~26.4V (24V±10%)				
Current	mA	Frequency	50Hz	60Hz	50Hz	60Hz	50Hz	60Hz
		AC100V	40	32	96	95	96	95
		AC200V	23	17	48	46	48	46
		DC24V	125		412		412	
Insulation resistance	MΩ	100 or more		100 or more				
Wiring		Grammet type (Lead wire length 300mm)		Grammet type (Lead wire length 300mm)				
Manual override		Locking and non-locking type		Locking type				
Surge suppression		Flywheel diode (only DC)						


Note: While there are two solenoids in the twin solenoid valves, for vacuum generation use and vacuum breaking use, the configuration prevents power from being sent to both of them at the same time.

Mass

Model	Item	Body mass	Additional mass			
			With filter	With vacuum switch	With single solenoid valve	With twin solenoid valves
ME12		40 [1.41]	25 [0.88]	—	80 [2.82]	—
ME25, 60		335 [11.82]	—	160 [5.64]	90 [3.17]	230 [8.11]


Calculation example: Mass of ME25 with a vacuum switch and twin solenoid valves is 335+160+230 = 725g [25.57oz.]

Order Codes




Operation Principle and Major Parts


● Not in operation



● When vacuum generation valve is ON




● When vacuum breaking valve is operating




Air Consumption, Vacuum and Vacuum Flow Rate


ME12



ME25



ME60




1MPa = 145psi. 1kPa = 0.145psi. -100kPa = -29.54in.Hg 1 l/min = 0.0353ft³/min.

Symbols


Single unit

ME12




With filter

ME12F ME25 ME60




With vacuum switch and filter

ME25-M ME60-M




With single solenoid valve

ME12-S




With single solenoid valve and filter

ME12F-S ME25-S ME60-S




With vacuum switch, single solenoid valve, and filter

ME25-M-S ME60-M-S




With twin solenoid valves and filter

ME25-T ME60-T




With vacuum switch, twin solenoid valves, and filter

ME25-M-T ME60-M-T




Dimensions of ME12 (mm)


●ME12




●ME12-S□



●ME12F




●ME12F-S□




Dimensions of ME25, ME60 (mm)


- ME25
- ME60




- ME25-M
- ME60-M




- ME25-S
- ME60-S




- ME25-M-S
- ME60-M-S



- ME25-T
- ME60-T




- ME25-M-T
- ME60-M-T



MICRO EJECTORS


Handling Instructions and Precautions




Micro ejector

Device configuration

●ME12



●ME25, 60




Piping

1. Connect air supply to the compressed air supply port, and a vacuum pad, etc., to the vacuum generation port.
2. For piping to the micro ejector, use a nylon or urethane tube with inner diameter of $\phi 4 \sim \phi 6$ [$\phi 0.157 \sim \phi 0.236$ in.]. For vacuum generation ports, tubes of the following sizes are recommended.
 - ME12 $\cdots \phi 4 \times 2.5 \sim \phi 6 \times 4$
 - ME25 $\cdots \phi 6 \times 4 \sim \phi 8 \times 6$
 - ME60 $\cdots \phi 8 \times 6 \sim \phi 10 \times 8$

- Cautions:**
1. Use a fitting that does not reduce inner diameter. A small inner diameter can result in degradation of performance, including flow rate and pressure shortages, insufficient vacuum, or longer periods of time before the vacuum level is reached.
 2. Avoid using coil tubes and other forms of spiraled piping. Also, avoid use of elbow fittings, etc., between the micro ejector and vacuum pad, and use piping that is as straight as possible.

Vacuum switch


When vacuum reaches the set vacuum level which is adjusted by a control nut, a micro switch operates, and an electrical signal is obtained. Move the cover in the direction of the arrow, and rotate the control nut to adjust the vacuum level. Rotate the control nut in the \downarrow direction to increase the set vacuum level to rise, and rotate it in the \uparrow direction to reduce the vacuum level.



Solenoid valve

The micro ejector includes an optional single solenoid valve for vacuum generation, and optional twin solenoid valves for vacuum generation and vacuum breaking air (twin solenoid valves are for ME25 and 50 only). The twin solenoid valves option uses supply pressurized air to the vacuum side to enable vacuum breaking and blow-off release, and makes use of a breaking flow adjustment valve to allow flexible setting of breaking and release time. In addition, a built-in check valve ensures that the vacuum level setting can be maintained even when the power to the vacuum generation solenoid valve has been switched off, enabling energy savings.


● Energy-saving circuit for maintaining vacuum over long periods




● Solenoid internal circuit

ME12

DC24V (surge suppression)




AC100V, AC200V (shading type)



ME25, ME60


For DC and AC (DC surge suppression)



- Cautions:**
1. Do not apply megger between the lead wires.
 2. The DC solenoid will not short circuit even if the wrong polarity is applied, but the valve will not operate.
 3. Leakage current inside the circuit could result in failure of the solenoid valve to return, or other erratic operation. Always use it within the range of the allowable leakage current. If circuit conditions, etc., cause the leakage current to exceed the maximum allowable leakage current, consult us.


● Adjustment of breaking flow rate

Rotate the adjusting needle for vacuum breaking flow rate in the clockwise direction to reduce the vacuum breaking flow rate and lengthen vacuum breaking time, and in the counterclockwise direction to increase the vacuum breaking flow rate and shorten breaking time.




Time to Reach Vacuum and Vacuum Breaking Time

● Measurement circuits and conditions



● Measurement method



Air pressure: 0.5MPa [73psi.]
 t₁: Time to reach -73.3kPa [-21.65in.Hg] in the chamber after energizing S1.
 t₂: Time to reach -18.7kPa [-5.52in.Hg] in the chamber after energizing S2.

● Response time


Chamber capacity cm ³ [in. ³]	s											
	10 [0.610]		50 [3.05]		200 [12.2]		1000 [61.0]		3000 [183]		5000 [305]	
Model	Time		t ₁	t ₂	t ₁	t ₂	t ₁	t ₂	t ₁	t ₂	t ₁	t ₂
ME12	1.5	—	2.0	—	4.0	—	7.5	—	26.0	—	50.0	—
ME25	1.0	0.1	1.3	0.1	2.0	0.2	3.8	0.4	13.0	1.5	23.0	3.0
ME60	0.5	0.1	1.0	0.1	1.5	0.2	3.0	0.4	10.0	1.5	15.0	3.0

Note: Some degree of variation may occur due to piping size and chamber shape.
 The figures can be viewed as a guide.

● Manual operation


ME12E1

To lock the manual override, use a small screwdriver to push down the manual override all the way and turn it 45 degrees or more. Either turning direction at this time is acceptable. When locked, turning the manual override from the locking position releases a spring on the manual override, returns it to its original position, and release the lock.



125EE1, 125EE2

To lock, use a screwdriver to rotate the manual override 45 degrees and tilt the screw groove 45 degrees. Either turning direction at this time is acceptable. To release the lock, rotate the manual override by 45 degrees, and return the screw groove to horizontal.



Caution: Always release the lock on the manual override before commencing normal operation.